

## Q9000D Touchpad Menu

### Features:

1. Output can be US or international
2. Escape key can be disabled
3. Control key can be disabled
4. Alt key can be disabled
5. Hidden Ctrl-Alt-Delete (← → Backspace) can be disabled
6. Hidden function keys (← → 1=F1 etc.) can be disabled
7. Hidden Delete key (Ctrl-Alt-Escape) can be disabled
8. Right Mouse button can be disabled

### To activate the menu:

1. Open a blank document in any word processor such as Word or Notepad.
2. Press shift-ctrl-alt-O-I-T at the same time.
3. The menu will look like the second page of this document.
4. Enter each option that is to be changed from the factory settings.
5. Press Enter and the options will be changed and displayed.

All menu changes can be protected.

### Option 1

**Menu Lock-** Make changes and enter “M” for menu lock. **All changes are permanent!** The only way to change them again is to send the keyboard back to the factory for reprogramming.

### Option 2

**Set Password-** Make changes and enter “S” for set password. All changes will be protected by the password chosen. Password can be changed or disabled using current password.

# Touchpad MENU

Q9000B USB w/Keytouch Navigator

©2007 Operator Interface Technology Inc. [www.oitkeypad.com](http://www.oitkeypad.com)

F/W OIT02F1v1.73 NETRONICS P.E. inc. [www.NETRONICS-PE.COM](http://www.NETRONICS-PE.COM)

s#00000397 c/s ECDC ←Unique Serial Number

Layout US

ESC Allowed

Right Mouse Right click

←/→ BS CTRL/ALT/DEL

←/→ digit fn

Navigator is Present

Navigator inner speed 100

←Does not apply to touchpad

Navigator outer speed 400

CTRL Transmitted

ALT Enabled

Menu Allowed

Password Cleared

Select:

Layout

U=US I=Int'l

ESC key

A=Allow D=Disallow

Right Mouse

R= Right Click L=leftClick(noRightClick)

←/→ BS combination

C=CTRL/ALT/DEL B=Blocked

←/→/digit combination

F=Fn Q=Quiet

← Disable the hidden function keys.

CTRL key Transmission

T=Transmitted H=Held

Alt key Enable

E= Enabled O=Off

Navigator

N=Not P=Present

Navigator inner speed m/s

5=50 1=100 2=200

←Does not apply to touchpad

Navigator outer speed m/s

3=300 4=400 6=600 0=unlimited

Menu Access

M=Menu Lock

← This setting permanently locks changes!

Password

S=Set Password

← This setting protects changes with a unique password

[Enter] to exit

>

Press Enter to exit menu

Please call 303-684-0094 if you need assistance with menu changes.